



H593 SCUD Vision Flow Ver 1.0

Station ID	Station Description	Vendor	Process Type		MIL
H593		COWAI N	Dispense		



ID	Type	Circle	Moc	MX	MY	MZ	TX	TY	TZ	TR	TA	Speed	AccSpeed	IOStatus	StartDel	EndDelay	StartDel	EndDelay	Section		
1	0	-1	-	-	-	-	-2.97	-0.15	0	0	0	10	10	0	0	0	0	0	02_1		
2	0	-1	-	-	-	-	-4.23	0.61	0	0	0	25	25	0	0	0	0	0	02_1		
3	0	-1	-	-	-	-	-4.43	1.91	0	0	0	25	25	1	0	0	0	0	02_1		
4	0	-1	-	-	-	-	-3.05	1.04	0	0	0	10	10	0	0	0	0	0	02_1		
5	0	-1	-	-	-	-	-3.21	0.94	0	0	0	25	25	0	0	0	0	0	02_1		
6	0	-1	-	-	-	-	-2.06	0.95	0	0	0	15	15	1	0	0	0	0	02_1		
7	0	-1	-	-	-	-	2.48	0.63	0	0	0	20	20	0	0	0	0	0	02_1		
8	0	-1	-	-	-	-	4.51	0.63	0	0	0	10	10	1	0	0	0	0	02_1		
9	0	-1	-	-	-	-	6.29	0.7	0	0	0	20	20	0	0	0	0	0	02_1		
10	0	-1	-	-	-	-	4.65	-0.36	0	0	0	20	20	1	0	0	0	0	02_1		
11	0	-1	-	-	-	-	3.05	-0.69	0	0	0	20	20	1	0	0	0	0	02_1		
12	0	-1	-	-	-	-	-1.68	-0.57	0	0	0	30	30	0	0	0	0	0	02_1		
13	0	-1	-	-	-	-	-2.94	-0.16	0	0	0	30	30	1	0	0	0	0	02_1		
MinX		-999	MaxX		999	MinY		-999	MaxY		999	MinZ		-999	MaxZ		999	MinA		-99	MaxA


ID	Type	Circle	Moc	MX	MY	MZ	TX	TY	TZ	TR	TA	Speed	AccSpeed	IOStatus	StartDel	EndDelay	StartDel	EndDelay	Section
1	0	-1	-	-	-	-	2.97	0.15	0	0	0	10	10	0	0	0	0	0	0_3_1
2	0	-1	-	-	-	-	4.23	-0.61	0	0	0	25	25	0	0	0	0	0	0_3_1
3	0	-1	-	-	-	-	4.43	-1.91	0	0	0	25	25	1	0	0	0	0	0_3_1
4	0	-1	-	-	-	-	3.05	-1.04	0	0	0	10	10	0	0	0	0	0	0_3_1
5	0	-1	-	-	-	-	3.21	-0.94	0	0	0	25	25	0	0	0	0	0	0_3_1
6	0	-1	-	-	-	-	2.06	-0.95	0	0	0	15	15	1	0	0	0	0	0_3_1
7	0	-1	-	-	-	-	-2.48	-0.63	0	0	0	20	20	0	0	0	0	0	0_3_1
8	0	-1	-	-	-	-	-4.51	-0.63	0	0	0	10	10	1	0	0	0	0	0_3_1
9	0	-1	-	-	-	-	-6.29	-0.7	0	0	0	20	20	0	0	0	0	0	0_3_1
10	0	-1	-	-	-	-	-4.65	0.36	0	0	0	20	20	1	0	0	0	0	0_3_1
11	0	-1	-	-	-	-	-3.05	0.69	0	0	0	20	20	1	0	0	0	0	0_3_1
12	0	-1	-	-	-	-	1.68	0.57	0	0	0	30	30	0	0	0	0	0	0_3_1
13	0	-1	-	-	-	-	2.94	0.16	0	0	0	30	30	1	0	0	0	0	0_3_1




Vision System Diagram

Parameter				
Pixels	FOV	Resolution	DOF	
2448*2048	21*17.5mm	0.008mm/pixel	2.5mm	
BOM(for Dual_station)				
Item	Type	Description	Brand	Quantity
Camera	LY-H500C	5MP Color camera	Luster	2
Lens	EGXD-RDTD-150-04	Telecentric lens	Luster	2
Light1	LY-CLS-RS-25-EX-M-D28	lighting sleeve	Luster	2
License	VW-VA-SW-GLUE10	/	Luster	1

Glue path 1
Golden image1




Detailed parameters of golden image1	
Pixel dimension	0.008mm
CCD resolution	2448*2048
Lens resolution	1000W, 1’
FOV	21mm*17.5mm
DOV	2.5mm
Lightning Brightness	200
Exposure time	20ms




Pose 1 Vision Workflow

Step	Description	Page	Remark
1	Creating coarse finder templates Pose1	8	
2	Pattern Matching in Pose1	9	
3	Finding lines	10	
4	Glue path AOI Product Glue Path Edge	15	
5	Glue path AOI Glue Area Region	16	
6	FOF	23	



Modeling Process



Template

The dialog box '显示图形控件' (Display Graphics Controls) contains the following parameters for the '仿射矩形' (Affine Rectangle):

Parameter	Value
中心 X:	1216.458
中心 Y:	1046.640
长度 X:	380.832
长度 Y:	195.606
旋转角度:	0.000 (°)
倾斜角度:	0.000 (°)
面积:	74493.3

Buttons: 确定 (OK), 取消 (Cancel)

Contour feature area parameter

The dialog box contains the following training parameters:

Parameter	Value
<input type="checkbox"/> 金字塔层数	层数: 5
<input checked="" type="checkbox"/> 自动噪声	噪声阈值: 11
<input type="checkbox"/> 自动边缘强度	边缘强度阈值: 4000


Training parameters

- Modeling feature requirements :
- 1. Stable and clear outline edge, no dirty
 - 2. Do not have multi-layer, complex contours
 - 3. Search area, do not have a close shape of the edge of the contour


When modeling, make good use of the masking function to mask out the unwanted edge contour features. Leaving only stable and clear contour features

After the modeling is completed, need offline test with all the previous material images to confirm the compatibility of this template for all incoming materials.

Subsequent parameter changes need to be synchronized and updated to all other machines in this station.



Matching process






ParameterList	
接受阈值	0.600000
对比度阈值	10.000000
重叠比例阈	0.800000
贪婪度	0.900000
搜索个数	1
是否开启全	否
搜索区域	708.168558,
是否外部输	否
搜索模式	快速
开启支持边	否
任意极性	否
自动金字塔	否

Matching parameter

工位1定位_4196搜索结果数组	[1]
[0]	{...}
二维线性变换	(-78.010565,181.570978),(0.985...
匹配点	(1100.795008,1218.578250)
角度	1.129471
分数	0.987555

Matching result



Result

编辑卡尺参数

可变矩形

卡尺宽度: 5

卡尺间距: 0

卡尺个数: 13

卡尺索引: -1

显示所有卡尺 ☐

搜索方向: ☒ 由左到右 ☐ 由右到左 ☐ 由里向外 ☐ 由外向里

确定 取消

编辑卡尺参数

可变矩形

卡尺宽度: 5

卡尺间距: 0

卡尺个数: 8

卡尺索引: -1

显示所有卡尺 ☐

搜索方向: ☒ 由左到右 ☐ 由右到左 ☐ 由里向外 ☐ 由外向里

确定 取消

编辑卡尺参数

可变矩形

卡尺宽度: 5

卡尺间距: 0

卡尺个数: 39

卡尺索引: -1

显示所有卡尺 ☐

搜索方向: ☒ 由左到右 ☐ 由右到左 ☐ 由里向外 ☐ 由外向里

确定 取消

编辑卡尺参数

可变矩形

卡尺宽度: 5

卡尺间距: 0

卡尺个数: 41

卡尺索引: -1

显示所有卡尺 ☐

搜索方向: ☒ 由左到右 ☐ 由右到左 ☐ 由里向外 ☐ 由外向里

确定 取消

属性参数 高级属性参数

边缘模式: 单边缘

边缘极性1: 亮到暗

对比度阈值: 30.000000 局外点比例: 0.100000

边缘属性: 最佳边缘

归一化范围: [-180,180]

属性参数 高级属性参数

边缘模式: 单边缘

边缘极性1: 亮到暗

对比度阈值: 10.000000 局外点比例: 0.100000

边缘属性: 最佳边缘

归一化范围: [-180,180]

边缘模式: 单边缘

边缘极性1: 亮到暗

对比度阈值: 20.000000 局外点比例: 0.100000

边缘属性: 第一条边缘

归一化范围: [-180,180]

属性参数 高级属性参数

边缘模式: 单边缘

边缘极性1: 亮到暗

对比度阈值: 10.000000 局外点比例: 0.100000

边缘属性: 最佳边缘


归一化范围: [-180,180]

L1 finding line parameters



L2 finding line parameters

L3 finding line parameters

L4 finding line parameters



Point demonstration process



L1 Caliper parameters



L2 Caliper parameters

- Incoming material requirements:
1. to ensure that the difference between the material and the modeled material can not be too large (visual inspection can not have obvious differences in the structure)
 2. dirty, foreign matter also can not have a lot, can not obscure the modeled features;

Glue Path AOI MSOP

The algorithm, inspection definition and spec of the glue path AOI.

H593 | Glue path AOI Product Glue Path Edge

No Glue


The areas of the glue > 0mm²

Glue Coverage-Shift


The R1/R2 coverage line should be >=100 % covered by glue path

Glue Missing

Pre-dispense image



Post-dispense image



Legend:



Glue Path Edge



Glue Coverage Line




Glue Area Region




Keep out zone

Pix accuracy:0.0086mm/pix


Region	No Glue	Glue Coverage-Shift	Glue Missing-Area
R1	Glue area > 0mm²	/	Glue area > 0.92mm²
R2	Glue area > 0mm²	/	Glue area > 1.15mm²
R3	Glue area > 0mm²	/	Glue area > 2.18mm²
R4	Glue area > 0mm²	/	Glue area > 1.36mm²
R5	Glue area > 0mm²	/	Glue area > 1.22mm²
R6	Glue area > 0mm²	/	Glue area > 0.82mm²



Source image (post-dispense)



extract glue color




extract result

missing
Step 2#

The purpose of this process is used to extract the Glue path
Step 1# Capture pose1 source image
Step 2# Extract the color of glue path
Step 3# Inspect the glue path


Audio | Glue path AOI Glue Area Region




The purpose of this process is used to find the position for dispense and region for coverage inspection:

- Step 1# Capture pos1 source image
- Step 2# RGB image to gray image
- Step 3# Pattern match to get the place of the product
- Step 4# Grab the product characteristics of line/circle to obtain L1, L2, L3, L4, P1, P2, P0 is middle point of P1&P2.
- Step 5# Establish a product coordinate system by using P0 and L3.
- Step 6# Place the glue inspection region according to product coordinate system


Pose1_Missing_R1 MIN: 1.3175



Pose1_Missing_R1 MAX: 2.4365




Pose1_Missing_R1 Data




R1 Missing spec= Pose1_Missing_R1 MIN*0.7=1.3175*0.7=0.92


Pose1_Missing_R2 MIN: 1.6518



Pose1_Missing_R2 MAX: 2.9191



Pose1_Missing_R2 Data






R2 Missing spec= Pose1_Missing_R2 MIN*0.7=1.6518*0.7=1.15

Pose1_Missing_R3 MIN: 3.1205


Pose1_Missing_R3 MAX: 4.179

Pose1_Missing_R3 Data




R3 Missing spec= Pose1_Missing_R3 MIN*0.7=3.1205*0.7=2.18


Pose1_Missing_R4 MIN: 1.9449



Pose1_Missing_R4 MAX: 3.186




Pose1_Missing_R4 Data




$R4 \text{ Missing spec} = \text{Pose1_Missing_R4 MIN} \times 0.7 = 1.9449 \times 0.7 = 1.36$


Pose1_Missing_R5 MIN: 1.7514



Pose1_Missing_R5 MAX: 3.5732




Pose1_Missing_R5 Data




R5 Missing spec= Pose1_Missing_R5 MIN*0.7=1.7514*0.7=1.22


Pose1_Missing_R6 MIN: 1.1789



Pose1_Missing_R6 MAX: 1.9133



Pose1_Missing_R6 Data



R6 Missing spec= Pose1_Missing_R6 MIN*0.7=1.1789*0.7=0.82

