



H565A SCUD Vision Flow Ver 1.0

Station ID	Station Description	Vendor	Process Type		MIL
H565A		Cowain	Dispense		




ID	Type	CircleMode	MX	MY	MZ	TX	TY	TZ	TR	TA	Speed	AccSpeed	IOStatus	StartDelay	EndDelay	StartDelay	EndDelay	ICSection		
1	0	-1	-	-	-	-4.624	0.358	-2	0	0	10	10	0	0	0	0	0	0 2 1		
2	0	-1	-	-	-	-4.104	0.608	-3	0	0	10	10	0	0	0	0	0	0 2 1		
3	0	-1	-	-	-	-3.494	0.818	-3	0	0	10	10	1	0	0	0	0	0 2 1		
4	0	-1	-	-	-	-2.124	0.898	-3	0	0	10	10	1	0	0	0	0	0 2 1		
5	0	-1	-	-	-	-1.244	0.938	-3	0	0	10	10	1	0	0	0	0	0 2 1		
6	0	-1	-	-	-	-0.194	0.828	-3	0	0	10	10	1	0	0	0	0	0 2 1		
7	0	-1	-	-	-	-1.204	0.828	5	0	0	10	10	0	0	0	0	0	0 2 1		
MinX	-999	MaxX		999	MinY	-999	MaxY	999	MinZ	-999	MaxZ	999	MinR	-999	MaxR		999	MinA	-99	MaxA

ID	Type	CircleMode	MX	MY	MZ	TX	TY	TZ	TR	TA	Speed	AccSpeed	IOStatus	StartDelay	EndDelay	StartDelay	EndDelay	ICSection			
1	0	-1	-	-	-	4.624	-0.358	-2	0	0	10	10	0	0	0	0	0	0 3 1			
2	0	-1	-	-	-	4.104	-0.608	-3	0	0	10	10	0	0	0	0	0	0 3 1			
3	0	-1	-	-	-	3.494	-0.818	-3	0	0	10	10	1	0	0	0	0	0 3 1			
4	0	-1	-	-	-	2.124	-0.898	-3	0	0	10	10	1	0	0	0	0	0 3 1			
5	0	-1	-	-	-	1.244	-0.938	-3	0	0	10	10	1	0	0	0	0	0 3 1			
6	0	-1	-	-	-	0.194	-0.828	-3	0	0	10	10	1	0	0	0	0	0 3 1			
7	0	-1	-	-	-	1.204	-0.828	5	0	0	10	10	0	0	0	0	0	0 3 1			
MinX		-999	MaxX		999	MinY		-999	MaxY		999	MinZ		-999	MaxZ		999	MinA		-99	MaxA

# Glue Dispense Vision Guidance

The algorithm and work flow to guide the machine to dispense the glue.




Vision System Diagram

Parameter			
Pixels	FOV	Resolution	DOF
2448*2048	21*17.5mm	0.008mm/pixel	2.5mm

BOM(for Dual_station)				
Item	Type	Description	Brand	Quantity
Camera	LY-H500C	5MP Color camera	Luster	1
Lens	EGXD-RDTD-150-04	Telecentric lens	Luster	1
Sleeve Module	LY-CLS-RS-25-EX-M-D28	Sleeve Module	Luster	1
Light 2	RBM-HBL10228-W	Bar light	Luster	1
License	VW-VA-SW-GLUE10	/	Luster	1


Glue path :  
Golden image  
 $A= 10^{\circ} \pm 0.5^{\circ}$   
 $R= 0^{\circ} \pm 0.5^{\circ}$



Detailed parameters of golden image

Pixel dimension	0.0086mm
CCD resolution	2448*2048
Lens resolution	1000W, 1'
FOV	21*17.5mm
DOF	2.6mm
Lightning Brightness	200
Exposure time	35ms







# Pose 1 Vision Workflow

Step	Description	Page	Remark
1	Creating coarse finder templates Pose1	9	
2	Pattern Matching in Pose1	10	
3	Finding lines and finding circles	11	
6	Glue path AOI Product Glue Path Edge	18	
7	Glue path AOI Glue Area Region	19	





Modeling Process



Template

显示图形控件

仿射矩形

中心 X: 1220.351

中心 Y: 1083.864

长度 X: 1291.131

长度 Y: 261.236

旋转角度: 0.000 (°)

倾斜角度: 0.000 (°)

面积: 337290.0

确定 取消

Contour feature areaparameter

参数

<input checked="" type="checkbox"/> 金字塔层数	层数:	4
<input checked="" type="checkbox"/> 自动噪声	噪声阈值:	40
<input type="checkbox"/> 自动边缘强度	边缘强度阈值:	600


Training parameters

- Modeling feature requirements:
- 1. Stable and clear outline edge, no dirty
  - 2. Do not have multi-layer, complex contours
  - 3. Search area, do not have a close shape of the edge of the contour


When modeling, make good use of the masking function to mask out the unwanted edge contour features. Leaving only stable and clear contour features

After the modeling is completed, need offline test with all the previous material images to confirm the compatibility of this template for all incoming materials.

Note: If the parameters are modified in the future, all other machines in this station need to be updated



Matching process



Actual product

ParameterList		
接受阈值	0.600000	
对比度阈值	10.000000	
重叠比例阈值	0.800000	
贪婪度	0.900000	
搜索个数	1	


工位1定位_4196.搜索结果数组	[1]	vector<scGeomSearchExResult>
[0]	{...}	scGeomSearchExResult
二维线性变换	(-31.468661,60.982142),(0.9920...	scPlanarLinearTransform
匹配点	(1156.350651,1161.872473)	scPlanarVector
角度	1.214723	double
分数	0.862178	double

Matching parameter


Matching result

- Incoming material requirements:
- 1. to ensure that the difference between the material and the modeled material can not be too large (visual inspection can not have obvious differences in the structure)
  - 2. region1 and region2 detection area, grayscale value and template material difference can not exceed  $\pm 10$
  - 3. dirty, foreign matter also can not have a lot, can not obscure the modeled features;

Note: If the parameters are modified in the future, all other machines in this station need to be updated



Line finding process



边缘模式	单边缘		
边缘极性1	亮到暗		
对比度阈值	10.000000	局外点比例	0.300000
边缘属性	最佳边缘		
归一化范围	[-180,180]		


Detailed parameters of L1'

编辑卡尺参数		×
可变矩形		
卡尺宽度:	3	
卡尺间距:	0	
卡尺个数:	26	
卡尺索引:	-1	
显示所有卡尺	<input type="checkbox"/>	
搜索方向:	<input checked="" type="radio"/> 由左到右	<input type="radio"/> 由右到左
	<input type="radio"/> 由里向外	<input type="radio"/> 由外向里
确定		取消


L1 Caliper parameters

- Search direction: Up to down, light to dark
- Capture features:
- 1. The contour edges are stable and clear, without any dirt or stains
  - 2. Do not have multiple layers or complex contours
  - 3. Within the search area, there should be no edge contours with similar shapes

Note: If the parameters are modified in the future, all other machines in this station need to be updated



Line finding process



L2 Caliper parameters




Detailed parameters of L2'


- Search direction: down to up, light to dark  
Capture features:
- 1. The contour edges are stable and clear, without any dirt or stains
  - 2. Do not have multiple layers or complex contours
  - 3. Within the search area, there should be no edge contours with similar shapes

Note: If the parameters are modified in the future, all other machines in this station need to be updated





Line finding process



边缘模式: 单边缘

边缘极性1: 亮到暗

对比度阈值: 10.000000 局外点比例: 0.300000

边缘属性: 最佳边缘

☒ 高级参数显示

☒ 启用掩膜 ☐ 手动模式

☒ 最优拟合 ☐ 重新评分

☐ 显示探测点 ☒ 减少局外点比例

圆心x上限:  圆心x下限:

圆心y上限:  圆心y下限:

半径上限:  半径下限:

Detailed parameters of C1

编辑卡尺参数

可变矩形

卡尺宽度:

卡尺间距:

卡尺个数:

卡尺索引:

显示所有卡尺: ☐

搜索方向: ☒ 由左到右 ☐ 由右到左 ☐ 由里向外 ☐ 由外向里

C1 Caliper parameters

Search direction: bottom to top, light to dark

Capture features:

1. The contour edges are stable and clear, without any dirt or stains
2. Do not have multiple layers or complex contours
3. Within the search area, there should be no edge contours with similar shapes

Note: If the parameters are modified in the future, all other machines in this station need to be updated


According to the template, establish the coordinate system, use the p point as a fixed offset, get the search box's center of finding line tool and finding contour tool

According to the set parameters and caliper parameters, find the correct line L1 and correct line L2 and correct circle C1


Get intersection P1 as the demonstrate point by L1 and C1, get intersection P2 as the demonstrate point by L2 and C1

P2 is the guiding point, make a line L3 cross P1 and P2, L3 is the reference angle


Point demonstration process




Detailed parameters of L1



Detailed parameters of L2




Detailed parameters of C1




Results

Note: If the parameters are modified in the future, all other machines in this station need to be updated






Point demonstration process



L1 Caliper parameters



L2 Caliper parameters

- Incoming material requirements:
- 1. to ensure that the difference between the material and the modeled material can not be too large (visual inspection can not have obvious differences in the structure)
  - 2. dirty, foreign matter also can not have a lot, can not obscure the modeled features;

---

# Glue Path AOI MSOP

The algorithm, inspection definition and spec of the glue path AOI.

# H565A | Glue path AOI Product Glue Path Edge

No Glue

The areas of the glue > 0mm²

Glue Coverage-Shift

The R1 coverage line should be >=80 % covered by glue path


Glue Missing

Glue Broken


The gap of glue breakage ≤ 0.1 mm

Region	No Glue	Glue Coverage-Shift	Glue Missing-Area	Glue Broken
R1	Glue area > 0mm²	≥80%	Glue area > 3.2mm²	≤0.1mm

Pre-dispense image



Post-dispense image




Legend:

- Glue Path Edge
- Glue Coverage Line
- Glue Area Region
- Keep out zone

Pix accuracy:0.0086mm/pix



Source image (post-dispense)



extract glue color



extract result


missing
Step 2#

The purpose of this process is used to extract the Glue path

- Step 1# Capture pose1 source image
- Step 2# Extract the color of glue path
- Step 3# Inspect the glue path




Audio | Glue path AOI Glue Area Region



The purpose of this process is used to find the position for dispense and region for coverage inspection:

- Step 1# Capture pos1 source image
- Step 2# RGB image to gray image
- Step 3# Pattern match to get the place of the product
- Step 4# Grab the product characteristics of line/circle to obtain L2&C1, P2 is intersection point of L2&C1
- Step 5# Establish a product coordinate system by using P2 and L3
- Step 6# Place the glue inspection region according to product coordinate system

Audio | Glue path AOI Glue Coverage Region



The purpose of this process is used to find the position for dispense and region for coverage inspection:

Step 1# Capture pos1 source image

Step 2# RGB image to gray image

Step 3# Pattern match to get the place of the product

Step 4# Grab the product characteristics of line/circle to obtain L2&C1, P2 is intersection point of L2&C1


Step 5# Establish a product coordinate system by using P2 and L3

Step 6# Place the glue inspection region according to product coordinate system




# H565A | Glue path AOI Product glue Inspection logic


Pose1\_Missing\_R1 MIN: 4.5902



Pose1\_Missing\_R1 MAX: 5.6861



Pose1\_Missing\_R1 Data



R1 Missing spec= Pose1\_Missing\_R1 MIN\*0.7=4.59\*0.7=3.21